



Powered by Android™ 15

Enterprise Mobility

MF52e

User Manual

Instruction

This manual provides information about basic features and using the MF52e. Please read this manual carefully before using your device and peripherals to ensure safe and proper use.



Note: Screenshots in this manual may differ from actual screens.

Revision History

Revision	Date	Description
v1.0		Initial release
V1.1	2026-07-25	Screenshot replacement and typo correction

Table of Contents

INSTRUCTION	1
Revision History	1
GETTING STARTED.....	4
Device Parts (0° Angle).....	4
Device Parts (20° Angle).....	6
Device Parts (60° Angle).....	8
Install SD & SIM Cards	10
Install & Remove Battery	11
Charge the Device	14
LED Indicator	17
Turn On / Off the Device	18
Use a Touch Screen	19
LEARNING THE BASICS	22
Setup Wizard	22
Home Screen.....	23
Call	32
Contacts	34
Message.....	36
MTP Connection with PC.....	37
Manage the Files	38
Lock the Screen.....	40
Settings	41
USING THE BUTTONS.....	43
Screenshot	43
Program Buttons.....	43
CAMERA.....	44


Table of Contents

SCANNER.....	45
Turn on / off the Scanner	45
ScanSettings	46
Scan a Barcode	55
ScanDemo.....	56
WIRELESS	57
Mobile Network.....	57
Wi-Fi	58
Bluetooth	59
NFC	62
RFID	62
SYSTEM MAINTENANCE	63
System Information.....	63
Check Device Health	64
OS Update.....	65
Factory Data Reset.....	68
ACCESSORIES	70
Hand Strap	70
SAFETY INFORMATION	72
Battery Safety Information	72

Getting Started

Device Parts (0° Angle)


Figure 1 MF52e front + left view



No	Name	Description
1	Receiver	Use with making a phone call
2	LED indicator	Indicate the power status and notification. Find more details in LED indicator
3	Scan button (Left)	Scan a barcode by pressing (Programmable button)
4	Volume buttons	Control the volume (Programmable button)
5	Microphone	Use for collecting sound
6	I/O connector for cradle	Connector with cradle for charging only
7	USB connector	USB Type C connector for charging and data communication
8	Speaker	Ring system sound
9	Touch screen	Displays all operating screen
10	Front camera	Take a picture

Getting Started

Figure 2 MF52e rear + right view




No	Name	Description
11	Hand strap hole (top / bottom)	Mount hand strap
12	Rear I/O connector	Connector for sled type accessories (gun handle)
13	Microphone	Use for collecting sound
14	Battery release buttons	Press the buttons in to release the battery
15	Emergency button	Perform emergency process
16	Scanner	Scan a barcode
17	Power button	Turn on/off the device
18	Rear camera & Flashlight	Take a picture & Use flashlight in camera or torch mode
19	Scan button (Right)	Scan a barcode by pressing (Programmable button)
20	Program button	Executes the configured program function.
21	Battery	Provide power (battery and battery cover are combined)

Getting Started

Device Parts (20° Angle)


Figure 3 MF52 front + left view



No	Name	Description
1	Receiver	Use with making a phone call
2	LED indicator	Indicate the power status and notification. Find more details in LED indicator
3	Scan button (Left)	Scan a barcode by pressing (Programmable button)
4	Volume buttons	Control the volume (Programmable button)
5	Microphone	Use for collecting sound
6	I/O connector for cradle	Connector with cradle for charging only
7	USB connector	USB Type C connector for charging and data communication
8	Speaker	Ring system sound
9	Touch screen	Displays all operating screen
10	Front camera	Take a picture

Getting Started

Figure 4 MF52e rear + right view




No	Name	Description
11	Hand strap hole (top / bottom)	Mount hand strap
12	Rear I/O connector	Connector for sled type accessories (gun handle)
13	Microphone	Use for collecting sound
14	Battery release buttons	Press the buttons in to release the battery
15	Emergency button	Perform emergency process
16	Scanner	Scan a barcode
17	Power button	Turn on/off the device
18	Rear camera & Flashlight	Take a picture & Use flashlight in camera or torch mode
19	Scan button (Right)	Scan a barcode by pressing (Programmable button)
20	Program button	Executes the configured program function.
21	Battery	Provide power (battery and battery cover are combined)

Getting Started

Device Parts (60° Angle)


Figure 5 MF52e MF52 front + left view



No	Name	Description
1	Receiver	Use with making a phone call
2	LED indicator	Indicate the power status and notification. Find more details in LED indicator
3	Scan button (Left)	Scan a barcode by pressing (Programmable button)
4	Volume buttons	Control the volume (Programmable button)
5	Microphone	Use for collecting sound
6	I/O connector for cradle	Connector with cradle for charging only
7	USB connector	USB Type C connector for charging and data communication
8	Speaker	Ring system sound
9	Touch screen	Displays all operating screen
10	Front camera	Take a picture

Getting Started

Figure 6 MF52e rear + right view



No	Name	Description
11	Hand strap hole (top / bottom)	Mount hand strap
12	Rear I/O connector	Connector for sled type accessories (gun handle)
13	Microphone	Use for collecting sound
14	Battery release buttons	Press the buttons in to release the battery
15	Emergency button	Perform emergency process
16	Scanner	Scan a barcode
17	Power button	Turn on/off the device
18	Rear camera & Flashlight	Take a picture & Use flashlight in camera or torch mode
19	Scan button (Right)	Scan a barcode by pressing (Programmable button)
20	Program button	Executes the configured program function.
21	Battery	Provide power (battery and battery cover are combined)

Ss

Getting Started

Install SD & SIM Cards


MF52e supports

- microSD card
- Nano SIM card – LTE/5G SKU only

You can find the card slots when removing the battery. Pull out the tray to install the SIM or microSD card


1. Remove the battery
2. Use your fingernail to catch the small notch (gap) at the top of the SIM card slot shown in the image below.

Figure 7 MF52e card slot



3. Carefully pull the slot outward to separate the SIM card slot.
4. Place the nano-SIM card and microSD card into the appropriate slots, making sure they are aligned correctly. (card tray with the card's gold contact is facing down)

Figure 8 Card tray layout



5. Insert the card tray back into the device.



Caution: Do not push or pull the tablet's card tray too hard. The card tray may be damaged.

Getting Started

Install & Remove Battery


Install the battery



Warning: Make sure the cardholders are completely closed before installing the battery. It may damage the device if you force to install the battery while the cardholders are not closed.

1. Insert the battery from the bottom side.


Figure 9 Installing battery – 1



2. Push the battery down until it clicks.

Confirm that the battery release buttons are completely outward and the bottom side is fully engaged.

Figure 10 Installing battery – 2




Getting Started

Remove the battery


1. Hold the battery release buttons and press in.

Figure 11 Removing battery – 1



2. While pressing the battery release buttons in, pull the battery up.

Figure 12 Removing battery – 2



Getting Started

Battery hot swap

Battery hot swap is a feature that allows users to replace the battery without powering off.

MF52e supports two types of hot swap mode, Enterprise hot swap, and Legacy hot swap. Basically, the device enters Enterprise Hot Swap mode. To use Legacy hot swap mode, disable Enterprise hot swap mode in EmSettings.

Enterprise hot swap

Enterprise hot swap allows the device to maintain Wi-Fi/Bluetooth connectivity and memory persistence even when detaching the battery. Users can earn time to replace the battery without stopping the ongoing task or disconnecting the Bluetooth devices.

But, as the backup battery with a smaller capacity than the main battery takes over to maintain the system, users are highly recommended to replace the battery within 30 seconds (30 seconds countdown displays). And some mitigations are activated to conserve power consumption.

- Reducing display brightness to about 10%
- Disabling NFC, Scanner
- Lowering sound volume

Once the user replaces the battery with a charged one, the device will come back to normal operation mode without booting process.



Caution: Do not change any settings or perform actions that may increase power consumption for device stability.

Legacy hot swap

When the battery is removed from the device, the display turns off, the device enters Hot swap mode and waits for battery replacement.

Once you replace the battery to a new one, the device will come back to normal operation mode without booting process.

Getting Started

Charge the Device

Before using MF52e, charge the device enough to use. Make sure the battery is installed before connecting the power adapter and charging the device. MF52e can be charged with power adapter or charging cradle. For best charging performance and safety, follow the normal [charging temperature](#).



Warning: Always use an original charger and cable from Point Mobile. Other chargers and cables may damage MF52e. Also, make sure the charger and cables are not wet.

Follow the [Battery Safety Information](#) for safety of using the battery.

Battery specification

- Capacity:
 - Standard battery: 4,670mAh
 - Extended battery: 7,000mAh
- Rechargeable & Removable battery

Charging temperature

Charge devices and batteries in temperatures from 0 °C to 45 °C. At out-of-normal range temperatures, the MF52e may stop charging for safety, and the power LED blinks red.

Getting Started


Smart Charging

MF52e supports three charging modes to provide optimal battery performance for your work.

- **Life-X mode (Default)**
 - An optimized charging mode that improves the battery's lifespan and stability.
- **Normal mode**
 - A typical charging mode.
- **Fast charging mode**
 - A charging mode that charges the battery faster than the other modes.

To change the smart charging mode, go to **Settings > Battery** or **EmKit > EmSettings**, and select **Smart Charging**.

Figure 13 Smart Charging




Getting Started

Charge with power adapter

1. Assemble the country plug, power adapter.
2. Connect the cable to the USB connector on the bottom side of MF52e.
3. Provide power by plugging the power adapter to the wall socket.

Figure 14 MF52e charging with power adapter




Getting Started

LED Indicator

MF52e has 2 LED indicators above the screen.

Figure 15 MF52e LED indicators



No	Indicator	Status	Indication
1	Power LED	 Solid green	Device is completely charged
		 Solid red	Device is charging / Battery is low
		 Blinking red	Charging temperature is out-of-normal range (Refer to Charging temperature) / Battery is very low
		 Alternately blinking red & green	Cannot recognize the battery
2	Notification LED	 Blinking blue	Notification existing
		 Red flash	Barcode reading failed
		 Blue flash	Barcode reading success


Getting Started

Turn On / Off the Device

To turn on the device,

- Press and hold the power button on the top of the device until **SMART BEYOND RUGGED** logo displays on the screen.


Figure 16 MF52e power button



To turn off the device,

- Press and hold the power button when the display is on until the power menu is shown. Then, tap **Power off**.



Figure 17 Power menu - Power off



Getting Started

Use a Touch Screen

Controlling the touch screen

Gesture	Description
	Tap One-finger press
	Double tap One-finger press, lift, one-finger press, lift for zoom in action
	Long-press One-finger press, wait, lift for select action
	Drag, Swipe, or Fling One-finger press, move, lift for scroll or tilt action
	Long-press drag One-finger press, wait, move, lift for pick up and move, or select multiple items action
	Scroll Vertical or horizontal swipe in a single direction
	Pinch Open & Close Two-finger press, move outwards and inwards, lift for zoom in / out action
	Rotate When MF52e is turning sideways, screen orientation is changing


Getting Started

System navigation

Navigation bar (Software button)

The navigation bar is enabled as a default, and it is located at the bottom of the screen. The app overview button, home button, and back button are placed on the bar in order.

Figure 18 Navigation bar



Shape	Button	Function
◀	Back button	Tap to go back to previous screen.
●	Home button	Tap to go to home screen. Long-press to launch the Google Assistant.
■	Recent apps button	Tap to see the recently used app list.

Getting Started

Gesture Navigation

If you are unfamiliar with the navigation bar or you want to see the screen with a wider screen, hide the navigation bar. The functions provided by the software buttons on the navigation bar can be used by using specific gestures.


To hide the navigation bar, navigate to **Setting**  **> System > Gesture > Navigation Mode** and change the setting to **Gesture navigation**. Then, the navigation bar will be hidden.



Note: To use the navigation bar again, change the setting to **3-button navigation**.

Find the gestures and matched function in the table below.

Figure 19 Gesture Navigation



Function	Gesture
Open recent apps screen	Swipe up from the bottom of the screen, hold, then release.
Go to home screen	Swipe up from the center-bottom of the screen.
Back to previous screen	Swipe from the left or right edge of the screen.
Launch Google Assistant	Swipe up from either the left-bottom or right-bottom.

Learning the Basics

Setup Wizard

When MF52e starts very first time or boot after factory reset, Setup Wizard is launched. Following the steps on the screen, set system language, Google Account, Wi-Fi connection and copy the data, etc.

Some settings can be skipped, but there may be some restrictions on the use of the system.

Figure 20 Setup Wizard (main)





Figure 21 Setup Wizard (Google Account)




Learning the Basics

Home Screen

Home screen is a screen displayed after Setup Wizard or pressing the Home button.

Figure 22 Home screen



No	Item	Description
1	Status bar	Indicates device status and notification.
2	Google	Search an item on Google
3	App	Tap to run the application Long-press to see the application's options
4	Favorites tray	Place the frequently used apps
5	App folder	Apps are organized in the folder. Tap to open the App folder

Learning the Basics

Status bar

Time, status icons, and notification icons are on the Status bar.

Status icons

Icon	Description	Icon	Description
	LTE connected		Strong signal
	3G connected		Weak signal
	VoLTE enabled		Connection issue
	Hotspot enabled		No data connection
	Airplane mode		Connected to a Bluetooth device
	Connected to a Wi-Fi network		Wi-Fi data communication
	Battery is full		Battery is low
	Battery is critical low		Cannot recognize battery
	Battery is charging		Alarm is set
	Location service turned on		Vibrate mode
	Speakerphone turned on		Phone mic is mute
	Scanner turned on		Scanner turned on, but trigger turned off

Learning the Basics

Notification icons


Icon	Description	Icon	Description
	Missed call		New SMS or MMS message
	New Email		Connected to VPN network
	Upcoming event		Other input method available
	File uploaded		File downloaded
	File copied		OTG device connected
	There are more notifications		

Notification panel

Notification panel displays a list of all notifications. Tap a notification to respond.

To open the Notification panel, drag the Status bar down. To close the panel, swipe it up.

Figure 23 Notification panel



Learning the Basics


Quick setting panel

Quick setting panel contains some frequently used settings such as Wi-Fi, Bluetooth, etc.

To use the Quick setting panel,

1. Open the Notification panel.
2. Drag down the Notification panel.
3. Tap a setting icon to enable / disable the setting or long-press an icon to see more detail.

Figure 24 Quick setting panel



To edit the configuration of Quick setting panel,

1. Tap  on the bottom of the panel.
2. By long-press and dragging the icon, customize the configuration of the panel.


Learning the Basics

Apps & Widget

App folder


To create the app folder, long-press an app icon and drag it to another app icon.

Figure 25 Create app folder



To change the folder name, tap the **Edit Name** and input a new name.

Figure 26 Change app folder name




Learning the Basics

App drawer

All installed apps are listed alphabetically in App drawer.

- To open the App drawer, swipe up the Home screen.
- To close the App drawer, swipe down the screen.

Figure 27 App drawer



Favorites tray

To organize an app in the Favorites tray,

1. Long-press an app icon from the App drawer. Then, drag it slightly until the Home screen is shown.
2. Place the app icon in the Favorites tray.

Figure 28 Add an app to Favorites tray



Learning the Basics


Organize app in Home screen

To organize an app in the Home screen,

1. Long-press an app icon from the App drawer. Then, drag it slightly until the Home screen is shown.
2. Place the app icon where you want.

(To cancel to place the app, drag it to **Cancel** area and release.)

Figure 29 Place app in Home screen




Learning the Basics

To remove an app or widget in the Home screen,

1. Long-press an app icon or widget.
2. Drag it to **Remove** area and release.

Figure 30 Remove from Home screen




Learning the Basics

Widget

To add a widget in the Home screen,

1. Long-press the empty space of the Home screen.
2. In three menus, select **Widgets**.

Figure 31 Widget menus



3. Among the list, tap and hold a widget you want to add.
4. Place the widget to the Home screen by dragging.

Learning the Basics

Call




Note: Calling is only available on LTE/5G SKU. And it requires a SIM card.

To make or receive a phone call, SIM card is required. Insert SIM card first regarding [Install SD & SIM cards](#).

Making a call

1. Tap **Phone**  from Home screen or App drawer.
2. Tap  to open a dialer.
3. Input a phone number.

Figure 32 Dialer




4. Tap  or  next to a searched number to make a call.

Learning the Basics

5. Control the Tap  to hang up the phone.

Figure 33 Calling screen




Icon	Function Name	Description
	Keypad	Open the keypad
	Mute	Mute microphone
	Speaker	Speakerphone mode
	(More) Add call	Add another call (Enable when receiver answer the phone)
	(More) Hold	Hold the call

Answering a call

Check the caller's name and number and tap **ANSWER** button to answer the phone call. Or tap **DECLINE** button to decline the phone call.

Figure 34 Receiving call



Learning the Basics

Contacts

Add a contact


Add a contact via dialer

1. Navigate to dialer through Phone, and enter the number.
2. Tap **Create new contact** or **Add to a contact** to save the number.
3. Input additional information.
4. Tap **Save**.

Add a contact via contacts app

Navigate to **Contacts**  from App drawer and tap  to add a new contact.

Figure 35 Add new contact via Contacts




Enter the contact details and tap **Save** on the top of the screen.

Learning the Basics

Contact detail


Select a contact from the list to find more detail information.

Figure 36 Contact detail



Tap  to open advanced options such as delete, share, block, etc.

Figure 37 Contact advanced options



Learning the Basics

Message




Note: Message feature is only available on LTE/5G SKU. And it requires a SIM card.

Send a message or find the received message through Message application .

1. Launch **Message**  from App drawer.
2. Tap **Start Chat** and type the receiver's name or phone number.

Figure 38 Message list



3. Input a message.
4. Tap  icon to send.

Figure 39 Message send




Learning the Basics

MTP Connection with PC

To transfer the files with a PC, connect the device to the PC via USB cable first.


1. Drag down Status bar and tap **Android System** notification to change USB preference option.

Figure 40 USB connection notification



2. Change the option to **File Transfer** from **No data transfer**.


Figure 41 USB Preferences



Learning the Basics


3. Now the PC can recognize the connected device. Find the MF52e device from the PC's file explorer.

Figure 42 File explorer on PC



Manage the Files

Figure 43 FileExplorer main screen




No	Description
1	Select a media file type or storage
2	Open the advanced option – Create a new window or folder, Select all files and folders, etc.
3	Search a file
4	Change the view of file list
5	Tap a file or folder to open. Or long-press a file or folder to select

Learning the Basics

Long-press a file (folder) or tap the icon which is located beside of file name to select the file (folder).

Figure 44 FileExplorer screen when file selected



No	Description
1	Share the file via Bluetooth / Gmail / Google Drive, etc. (Sharing is possible only with files)
2	Delete the files or folders
3	Open the advanced option - Open with: Select which app to open the file - Sort by...: Sort the list by file name, size, type, etc. - Select all: Select all files and folders - Copy / Move to: Copy or move the file to a new location - Compress: Create Zip file with the selected files or folders - Rename: Rename the file or folder - Get info: Display the file information
4	Selected file or folder is highlighted


Learning the Basics

Lock the Screen

Protect the device from unauthorized personnel by setting up the screen lock.

1. Navigate to **Settings**  > **Security & privacy** > **Device unlock**.
2. Tap **Screen lock**.

Figure 45 Screen lock



3. Choose a screen lock method.
 - None: Screen unlocks immediately
 - Swipe: Swipe the lock screen to unlock (Default)
 - Pattern: Draw a pattern to unlock
 - PIN: Input a PIN to unlock (At least 4 digits)
 - Password: Input a password to unlock (At least 4 characters)

Learning the Basics

Settings

There are two ways to go to **Settings**:

- Open the App drawer and tap **Settings** 
- Open the Quick setting panel and tap gear icon 

Adjust display brightness

To adjust the display brightness level,

- Open Quick setting panel and adjust display brightness bar
- Go to **Settings**  > **Display** > **Brightness level**

Figure 46 Normal brightness level



Figure 47 High brightness level (higher than 81%)




Warning: Using high brightness levels for long periods may cause eye strain and increase battery consumption.

Adjust sound

To adjust sound volume, go to **Settings**  > **Sound** and control the Media, Call, Alarm volume bars.

Figure 48 Volume bars



Warning: Using high volume levels for long periods may cause ear strain and increase battery consumption.


Learning the Basics

Adjust display and text size

If the display and text size too small or too large, adjust the size.

1. Go to **Settings**  > **Display** > **Display size and text**.
2. Referring to the **Preview**, adjust the size controller.

Figure 49 Set font size



Using the Buttons

Screenshot

To take a screenshot, use one of the two ways as below.

- Press and hold **Power button + Volume down button** simultaneously.
- Press and hold the power button, and then tap **Screenshot** among the power menus.


The screenshot image will be saved to **Pictures > Screenshots** folder in the internal storage.

Program Buttons

Most buttons on MF52e except power button can be optimized as you want. To map the button to other functions from default,

1. Navigate to **EmKit > Program Buttons** 
2. Tap **SMART REMAP**. And press a button you want to remap.

Figure 50 Program Buttons - Button list




Note: *SCANNER_B* indicates the trigger button on the gun handle and *Finger_Print* indicates the program button on the right side.

3. Choose a behavior you want to use among the tabs.
4. Tap **APPLY**.

Camera

To use the camera, open App drawer and tap Camera application . Figure 51 is a main screen of Camera application.

Figure 51 Camera main screen



No	Name	Description
1	Picture / Video	Swipe to the left and select to change the mode (Picture / Video)
2	Setting	Choose resolution and image quality settings
3	Gallery	Tap to see the recently taken pictures
4	Advanced camera option	 : Display the grid on the screen  : Set timer  : Set flash mode (Activate / Deactivate / Auto mode)  : Switch the camera (Front / Rear)
5	Shutter button	Take a picture or recode a video

Scanner

Scanner is placed on the top of the device. Optimize the scanner settings for working environment and improve the efficiency.


Turn on / off the Scanner

The scanner is turned on by default. You can check the scanner status by the icon  on the status bar. If the icon displays, the scanner is turned on.

If the scanner is turned off, follow the steps to turn it on.

1. Go to **EmKit**  or **Settings**  and tap **ScanSettings**.
2. Tap toggle button to turn on/off the barcode scanner.
3. Check if the scanner icon  is placed on Status bar.

Figure 52 Turn on scanner



Scanner

ScanSettings

When the scanner is turned on, scanner setting menus will be displayed. **ScanSettings** consists of

- Basic
- Options
- Notification
- Wedge
- Symbolologies
- About

Basic

Control the scanning options and wedge mode options.

1. Scanning

- Change the scanner's trigger timeout and set scan mode (single / auto / continuous / multi scan).
- Enable or disable the TouchScan, which is a software scanner button. Place a scan icon in any position and tap the icon to read a barcode.

Figure 53 ScanSettings - Basic





Figure 54 ScanSettings - TouchScan



Scanner

2. Wedge mode

- Change the result type of decoded data among the below list.
 - User Message
 - Keyboard Event (Multiple)
 - Keyboard Event (Single)
 - Clipboard (KEYCODE_PASTE)
 - Clipboard (Ctrl + V)
 - Intent Broadcast
 - Custom Intent
- Set Terminator as,
 - None
 - Space
 - Tab
 - LF
 - Tap & LF

Options

Enable / Disable the center window, Aimer, Illumination. And set scanner decoding settings.

Figure 55 ScanSettings - Options


Options	
On	☒
Options	
Enable center window	☐
Center window tolerance	50
Decode mode	Standard
Delay before decoding(sec)	0 seconds
Inverse 1D mode	Regular Type Only
Power save mode	☐
Power save timeout(sec)	60 seconds
Enable aimer	☒
Enable illumination	☒

Scanner

Notification

Control the beep sound, LED, display notification, and vibration option when scanning the barcode.

Figure 56 ScanSettings - Notification



Scanner

Wedge

Set below items in Wedge settings

- Barcode ID
- AIM ID
- Group separator
- Prefix
- Suffix
- Character set
- Extended Wedge

Figure 57 ScanSettings - Wedge

Wedge

On

Barcode ID

Transmit barcode ID

Transmit AIM ID

Group separator

GS

Label

Prefix

Suffix

Character set

Charset

UTF-8

Extended wedge

Enable extended wedge


Configuration extended wedge

Scanner

Extended wedge

MF52e supports Extended wedge that allows to edit the decoded data. Tap **Enable extended wedge** toggle switch and then set a rule in **Configuration extended wedge**.


Figure 58 ScanSettings - Extended wedge



For example, make a rule that add a string “*Point Mobile*” at the start of decoded data whenever decoding CODE128.

1. Tap **Style** (1) and select **Condition** (2).


Figure 59 Extended wedge example_1



Scanner


2. Tap **Symbologies** and select **CODE128** among the symbologies.

Figure 60 Extended wedge example_2



3. Tap **Style (1)** and select **Actions (2)**.


Figure 61 Extended wedge example_3



Scanner


4. Tap **ADD** and select **Move to start** to point the start of the decoded data.

Figure 62 Extended wedge example_4



5. Add another action of which action type is Send string. Set value as *"Point Mobile"*.

Figure 63 Extended wedge example_5



Scanner

6. “*Point Mobile*” string will be added to decoded CODE128 data.


Before	After
ScanDemo Type : CODE 128 Result : ABC-abc-1234 Record : Success Count :: 1/1 Success Time :: 1231 ms Avg Time :: 1231 ms Min/Max Time :: 1231 ms/1231 ms ☐ Continuous Scan ☐ Save Log ☐ Auto Scan ☒ Beep Sound Start scan	ScanDemo Type : CODE 128 Result : POINT MOBILEABC-abc-1234 Record : Success Count :: 1/1 Success Time :: 682 ms Avg Time :: 682 ms Min/Max Time :: 682 ms/682 ms ☐ Continuous Scan ☐ Save Log ☐ Auto Scan ☒ Beep Sound Start scan

Scanner

Symbologies

Enable or disable the specific symbology or set detail options. By tapping each symbology name to access detail options.


Figure 64 ScanSettings - Symbologies



About

Find the scanner information or restore the scanner settings to default.

Figure 65 ScanSettings - About



Scanner

Scan a Barcode

Point the scanner at the barcode and press the scan button on the device or gun handle. If another button is set as scan trigger using Program buttons (Refer to [Use the Buttons – Program buttons](#)), it can trigger the scan action, too.

**Note:**

If you set the single scan mode as Press decoding or Release decoding, it may require another button pressing mechanism to trigger scanning. Refer to [Single Scan Mode article](#) for more detail.

S0703 Scanner SKU

Center the cross-hair laser aimer over the barcode. The barcode must be within the square made by the edge of the aimer. You can tilt the aimer slightly for a comfortable angle to scan.

Figure 66 Aiming barcode (S0703)




Scanner

ScanDemo

Using ScanDemo app, demonstrate scanning feature.

1. Execute **EmKit > ScanDemo** .
2. Scan a barcode by pressing the scan button on the device or tapping **Start scan** button on the screen.
3. Find scan result.

Figure 67 ScanDemo



Wireless

Mobile Network



Note: Mobile network is supported on MF52e LTE/5G SKU only.
Check if your device is LTE/5G SKU.

To connect mobile network, SIM card is required. Insert SIM card first referring [Install SD & SIM cards](#).


After inserting the SIM card, reboot the device. When network is connected, a network icon will be appeared on the status bar.

Figure 68 Mobile network icon



Find network information and adjust the network settings in **Settings**  > **Network & internet** > **Mobile network**.

Figure 69 Mobile network setting




Wireless

Wi-Fi

To turn on and connect a Wi-Fi,

1. Go to **Settings**  > **Network & internet** > **Internet**.
2. Tap Wi-Fi toggle switch to enable Wi-Fi.
3. Device searches for nearby Wi-Fi signals and lists them in order of signal strength.
4. Select a Wi-Fi SSID to connect.
5. The message **Connected** under the SSID means the device complete to connect to the Wi-Fi.

Figure 70 Wi-Fi connected



Note: There are Open Wi-Fi network and Secured Wi-Fi network. You can tell those apart by lock icon (🔒) in the nearby Wi-Fi list.

To connect the secured Wi-Fi network, you need to enter the password.

Figure 71 Open Wi-Fi Network







Figure 72 Secured Wi-Fi Network



If there is a saved Wi-Fi network, simply turn on the Wi-Fi through the Quick setting panel. The saved network will be connected automatically.

Figure 73 Wi-Fi on Quick setting panel



Wireless


Bluetooth

Turn on / off

Bluetooth is turned off as default. There are two ways to turn on the Bluetooth,

- Open quick setting panel and enable  Bluetooth

Figure 74 Bluetooth in Quick setting panel




- Go to **Settings**  > **Connected devices** > **Pair new device**

Pair and Connect

To connect with a new device,

1. Go to **Settings**  > **Connected devices**.
2. Tap **Pair new device**.
(Bluetooth will be turned on automatically)
3. Select the device you want to pair among **Available devices** list.

Figure 75 Bluetooth available devices




4. Follow instructions on the screen (Pairing code or pairing confirmation dialog) and tap **PAIR**.

Wireless


5. When the connection is succeeded, the connected device name is listed under the **Other devices** list.

Figure 76 Bluetooth currently connected



To connect a device previously connected, select the device name from the **Saved devices** list.

Figure 77 Previously connected devices




Unpair and Disconnect

To unpair (forget) the device, select the name of the device you want to unpair from the **Other devices** list and tap **FORGET** .

Or tap **DISCONNECT**  to disconnect only and not unpair.

Figure 78 Bluetooth device details




Wireless

Change the Bluetooth device details

Tap the  icon next to the device name to see device details.

If the device you want is not listed under the **Saved devices**, tap **See all**.

Figure 79 Bluetooth device detail button



- To change the device's name, tap  on the top of the screen
- Turn other settings on or off (Available on some devices)

Wireless

NFC

MF52e's NFC antenna is located at the 1/3 top of the display. Bring the NFC tag close to the tapping area as Figure 80.

NFC feature is enabled by default.

But if NFC does not work, make sure the NFC is enabled from the **Settings**  > **Connected devices** > **Connection preferences** > **NFC**.

Figure 82 MF52e NFC tapping area




Figure 81 MF52e NFC tapping



RFID

MF52e can get RFID tag data through RF88 (sold separately). MF52e and RF88 can be connected using Bluetooth or wired connection.

To connect the devices, **RFID Control** application is required. You can download the app from Service Portal.

If you want to install the MF52e onto the RFID reader, a MF52e-dedicated sled bracket must be assembled on the RF88.



Note: Find more detail in RF88 User manual.

System Maintenance

System Information

There are two ways for checking system information, on settings and on EmKit.

On Settings

Go to **Settings**  > **About phone**. Following information can be found.

- Device name
- Phone number
- Legal information & Certificates
- SIM status
- Model & Hostname
- IMEI
- Android version
- IP address
- Wi-Fi / Device Wi-Fi MAC address
- Bluetooth address
- Uptime
- Build number

On EmKit

Go to **EmKit**  > **System Information** . Following information can be found.

- Processor information
- Version information (Android version, OS image version, SDK version, etc.)
- Manufacturer information (Serial number, Part number, etc.)
- Device information (Scanner, Audio, Display, etc.)
- Battery information (Battery charging status, etc.)
- App version information (Version of EmKit apps)

System Maintenance


Check Device Health

EmHealthReport is a solution that provides the device's battery and eMMC health.

Monitor the battery and eMMC status to foresight their lifetime or find the cause when there is a battery problem such as cannot charge the device or rapid battery discharge.

To use, open **EmKit** and launch **EmHealthReport** . You can see the simple device health information on the main screen. To find detailed information, tap each blue arrow on the right side of the screen.

Figure 83 EmHealthReport



- **Battery Health**
 - Battery Serial Number
 - Battery Age
 - Remaining Life
 - Charge/Discharge cycle count
 - Battery replacement index
 - Battery Level
 - Battery Voltage
 - Battery Temperature
 - System Temperature
 - Smart Charging Mode

(Refer to [Smart Charging](#))
- **eMMC Health**
 - Pre-EOL Information
 - Device life time estimation type A
 - Device life time estimation type B

System Maintenance

OS Update

Periodic update improves the performance of the device. Point Mobile provides up-to-date OS version via Service Portal and FOTA. Update the device via storage, OTG port, and FOTA server. Depending on the workspace environment, choose more suitable method.




Caution: Please backup your data before starting the update process.

OS update via storage

To update the OS using storage,

1. Download an OS image file into the root folder of microSD card or device internal storage.
2. (In case of using SD card) Insert SD card to the device and then turn the device on.
3. Go to **Settings**  > **System** > **System Update**.
4. Check if the OS image file shows up under **AVAILABLE VERSIONS**.

Figure 84 OS update via storage



5. Tap **UPDATE** to start the update process



Note: If the OS image file doesn't show up in **AVAILABLE VERSIONS**, check the file is placed in the root folder of storage. System only can recognize the file in the root folder.

System Maintenance

OS update via OTG port

MF52e supports the USB OTG feature.


1. Prepare a formatted USB flash drive for OS update.
2. Copy an OS image file to the root folder of the flash drive.
3. Connect the flash driver to the MF52e.
4. Go to **Settings**  > **System** > **System Update**.
5. Check if the OS image file shows up under **AVAILABLE VERSIONS**.
6. Tap **UPDATE** to start the update process.

OS update via FOTA

If MF52e can connect to a network, use the FOTA server for the update.

1. Connect the device with a network.
2. Go to **Settings**  > **System** > **System Update**.
3. Tap **FOTA** tab or Swipe left to move to **FOTA** tab.
4. If there is an OS version newer than device's one, the server shows the new OS information.

Figure 85 OS update via FOTA




System Maintenance

5. Tap **Download**.
6. Tap **OK** on the **OS Update** dialog to start to download the OS image file.
7. To complete the update, rebooting is required.
Tap **OK** on the **Restart required** dialog to restart the device.

Note: Basically, OS update via FOTA works over Wi-Fi or Ethernet only.
To enable the OS update over Mobile Network too, uncheck the setting value in FOTA Settings.
Downloading over the Mobile network may result in additional charges.

Figure 86 FOTA Settings



System Maintenance

Factory Data Reset

When the MF52e works abnormal or there is a need to reset the device, follow the steps below to perform a factory data reset.




Warning: Factory data reset will erase all personalized settings and data saved in the device, such as Google account, apps, user data, etc. And factory data reset cannot undo.

Factory data reset via Settings app

If the device can be turned on and access **Settings**,

1. Navigate to **Settings**  > **System** > **Reset options**.
2. Tap **Erase all data (factory reset)**.
3. After being aware that factory reset will erase all data from the internal storage, tap **Erase all data**.

Figure 87 Factory data reset



4. Tap **Erase all data** again to start the factory reset process


System Maintenance

Factory data reset via recovery mode

If device works abnormal so does not turn on, try to perform factory data reset through Android recovery mode.


1. Press and hold **power button + Volume Up** buttons simultaneously when MF52e is turned off.

Figure 88 Key combination for recovery mode



2. After short vibration, release the buttons.
3. When the device enters the recovery mode as below, select **Wipe data/factory reset** using the following buttons.
 - **Move up/down** – Volume up/down
 - **Select the menu** – Power button

Figure 89 Android recovery mode



4. Select **Factory data reset**.
5. After wiping the data, select **Reboot system now**.

Accessories

MF52 supports below accessories.

Category	Accessory Name	Usage
Hand strap	Hand strap	Carries MF52 easily


Hand Strap

Attach the strap to hold the device more firmly.

Attach hand strap


1. Press the wide hook of the hand strap into hand strap hole on the bottom until it clicks into place.

Figure 90 Attaching hand strap - 1



2. With the lower hook secured, attach the short hook of the hand strap to the upper hand strap slot on the MF52e.


Figure 91 Attaching hand strap - 2



Accessories

3. Make sure both hooks are securely fastened in the correct positions.

Figure 92 Attaching hand strap - 3



Safety Information

Battery Safety Information

Follow the battery safety guidelines for safe usage, storage, and disposal of Li-ion batteries. Improper battery use may result in a fire, explosion, or other critical hazards.

Battery Safety Guidelines

- Use only Point Mobile approved batteries and charging accessories. Other batteries and chargers may damage the device or result in a fire, leakage, or other hazards.
- Do not expose the battery to excessive heat or cold.
- Do not use or store the battery in or near areas that might get very hot, such as in a parked vehicle, near a heat duct or close to other heat sources.
- Do not allow objects that may cause a short circuit, such as metal objects, corrosive substances, or liquids like water, to contact the battery.
- Do not disassemble, crush, bend, shred, press, or other actions that may damage or deform the battery.
- Do not use or replace the battery on the go or from a high location. Dropping may result in an explosion or fire.
- Do not put any labels, stickers, tags, etc. on the device or battery. Performance of the device or battery, such as sealing, drop, or tumble, could be affected.
- Close supervision is necessary when used near children to avoid the risk of injury.
- If battery leakage is observed, avoid any contact with the skin or eyes and properly dispose of the battery. If contact has been made, wash the affected area with water for 15 minutes and seek medical advice.
- If you notice any type of damage to the battery, such as swelling, dents, and leaks, stop using it immediately and contact Point Mobile.

Battery Charging Guidelines

- Charge the battery in a clean, cool, dry, and ventilated environment.
- Separate the charger from the battery as soon as possible when the battery is fully charged.
- Battery performance can degrade due to the stress of daily charging and discharging. Batteries typically need to be replaced after 300 to 500 charging cycles (full charge-discharge cycles) or when the battery capacity has been reduced to 70 ~ 80% of its original capacity. The actual number of charging cycles varies based on usage patterns, temperature, age, and other factors.

Safety Information

Battery Storage / Disposal Guidelines

- Store the batteries in a clean, dry and ventilated environment within ambient temperature ranges of $20\pm5^{\circ}\text{C}$.
- For safety regulations, batteries are charged to below 20~30% of full capacity during production.
- When not using batteries for a long period, charge the battery for 30 minutes to 1 hour at least once every 6 months to prevent full discharge and keep the performance.
- Batteries should be stored separately when storing for long periods. Disconnect from any device, charger, or cradle.
- Dispose of used batteries promptly according to local disposal regulations.
- Do not dispose of the battery in fire. It may cause explosion.



Warning: The battery is consumable. Point Mobile provides a warranty for the battery for 12 months after purchase. If you suspect the battery swelling, change the battery immediately and contact Point Mobile.



POINT MOBILE Co., Ltd.

Offline

Tel: +82-2-3397-7870~1

Fax: +82-2-3397-7872

Address: 26F, Building A, Gasan Publik,
178, Digital-ro, Geumcheon-gu, Seoul, Korea 08513

Online

Website: <https://www.pointmobile.com>

E-mail : pm_ta@pointmobile.com